



# ONLY A **BD** DIAMOND INSTALLATION DEALER HAS THE OPPORTUNITY TO SELL & INSTALL 68 RFE TRANSMISSIONS



**REQUIREMENTS: HAVE THE PROPER TOOLS AND KNOWLEDGE**

### YOU ALSO REQUIRE

- An Transmission Flushing Machine
- An Approved Scanner
- Pressure Testing Adapter Tool

You will need to read through our 68 RFE operation and installation manual to complete the enclosed questionnaire available on our website:

<https://www.dieselperformance.com/shop?search=106426>

Once all answers are completed please mail them with a picture of your transmission flushing machine, a listing of the scanner

Technician's Name  
Whom Completed the Exam: \_\_\_\_\_

Company Name: \_\_\_\_\_

Address: \_\_\_\_\_

City: \_\_\_\_\_ Prov/State: \_\_\_\_\_ Postal Code/Zip Code: \_\_\_\_\_

Phone Number: \_\_\_\_\_ Fax Number: \_\_\_\_\_



#### Head Office

33541 MacLure Rd. Abbotsford, BC V2S 7W2

Toll Free: 1-800-887-5030

Telephone: 604-853-6096

Fax: 604-853-8749

Email: sales@bd-power.com

Website: dieselperformance.com

1. To perform a drive learn the transmission fluid temperature must be above
  - a. 70-100F
  - b. 80-110F
  - c. 90-120F
  - d. 100-130F
  
2. Where is the transmission Quick Learn found in the scan tool menus?
  - a. PCM or TCM - Data - Misc Functions - Quick Learn
  - b. PCM or TCM - System Tests - Quick Learn
  - c. PCM or TCM - Misc Functions - Quick Learn
  - d. PCM or TCM - Misc Functions - PCM or TCM Reset
  
3. What position must the throttle be in during the initial drive learn?
  - a. 15%
  - b. 20 degrees
  - c. 15 degrees
  - d. 20%
  
4. When must a Quick Learn be performed?
  - a. After transmission replacement or repair, before Line Pressure Module and aftermarket tuner is installed
  - b. After a transmission service
  - c. After a 60 mile break in period
  - d. After transmission replacement or repair, after Line Pressure Module and aftermarket tuner is installed
  
5. When are the CVI values to be recorded?
  - a. Before repair, after Quick Learn and after Drive Learn
  - b. After Quick Learn and Drive Learn
  - c. After Drive Learn only
  - d. Before repair and after Quick Learn



**Head Office**

33541 MacLure Rd. Abbotsford, BC V2S 7W2

Toll Free: 1-800-887-5030

Telephone: 604-853-6096

Fax: 604-853-8749

Email: [sales@bd-power.com](mailto:sales@bd-power.com)

Website: [dieselperformance.com](http://dieselperformance.com)

6. How do I know when a Drive Learn is complete?

- a. When the transmission has upshifted through all gears 10 times
- b. When CVI values are all matching
- c. When the transmission has up shifted through all the gears with same consistency and firmness
- d. When the CVI values are stabilized and the transmission upshifts through all gears with the same consistency and firmness

7. What will cause the 68RFE transmission to start a relearn on its own?

- a. Failed or intermittent sensor
- b. Power level change from aftermarket tuner
- c. Faulty electrical connection
- d. All of the above

8. Which tools are required to properly test and setup 68RFE transmission?

- a. 300 psi oil filled gauge
- b. Line pressure adaptor
- c. Scan tool able to read CVI values and perform a Quick Learn
- d. All of the above

9. A relearn is not required if?

- a. The aftermarket tuner setting are adjusted, power level is not
- b. The aftermarket tuner is updated
- c. The vehicle batteries are disconnected or replaced
- d. The vehicle ECM, PCM or TCM is reflashed

10. How is the Drive Learn initiated?

- a. With the vehicle at normal operating temperature stop in drive then accelerate at a 15 degree throttle angle upshifting through the gears
- b. With the vehicle at normal operating temperature stop in manual 1st then accelerate at a 15 degree throttle angle upshifting manually through the gears
- c. With the vehicle at normal operating temperature place transmission in neutral for 2-3 seconds then into drive and accelerate at a 15 degree throttle angle while upshifting through the gears
- d. With the vehicle at normal operating temperature place the transmission in reverse for 2-3 seconds then into drive and accelerate at a 15 degree throttle angle through the first 4 gears



**Head Office**

33541 MacLure Rd. Abbotsford, BC V2S 7W2

Toll Free: 1-800-887-5030

Telephone: 604-853-6096

Fax: 604-853-8749

Email: [sales@bd-power.com](mailto:sales@bd-power.com)

Website: [dieselperformance.com](http://dieselperformance.com)